



# METALLIC



**SOTTOPIATTO**  
Charger  
Ø 310 mm - 12 1/8"  
CT12 - Q.P. 552  
Cod. 4.50010  
Cod. dec. 620



**PIATTO PIANO**  
Dinner plate  
Ø 270 mm - 10 5/8"  
CT12 - Q.P. 1.008  
Cod. 4.50030  
Cod. dec. 620



**PIATTO FONDO**  
Soup plate  
Ø 230 mm - 9 1/8"  
CT12 - Q.P. 960  
Cod. 4.50040  
Cod. dec. 620



**PIATTO DESSERT**  
Dessert Plate  
Ø 210 mm - 8 1/4"  
CT12 - Q.P. 1.260  
Cod. 4.50050  
Cod. dec. 620



**SOTTOPIATTO**  
Charger  
Ø 310 mm - 12 1/8"  
CT12 - Q.P. 552  
Cod. 4.50010  
Cod. dec. 394



**PIATTO PIANO**  
Dinner plate  
Ø 270 mm - 10 5/8"  
CT12 - Q.P. 1.008  
Cod. 4.50030  
Cod. dec. 394



**PIATTO FONDO**  
Soup plate  
Ø 230 mm - 9 1/8"  
CT12 - Q.P. 960  
Cod. 4.50040  
Cod. dec. 394



**PIATTO DESSERT**  
Dessert Plate  
Ø 210 mm - 8 1/4"  
CT12 - Q.P. 1.260  
Cod. 4.50050  
Cod. Dec. 394





# METALLIC



**SOTTOPIATTO**  
Charger  
Ø 310 mm - 12 1/8"  
CT12 - Q.P. 552  
Cod. 4.50010  
Cod. dec. 395



**SOTTOPIATTO**  
Charger  
Ø 310 mm - 12 1/8"  
CT12 - Q.P. 552  
Cod. 4.50010  
Cod. dec. 630



**SOTTOPIATTO**  
Charger  
Ø 310 mm - 12 1/8"  
CT12 - Q.P. 552  
Cod. 4.50010  
Cod. dec. 600



**SOTTOPIATTO**  
Charger  
Ø 310 mm - 12 1/8"  
CT12 - Q.P. 552  
Cod. 4.50010  
Cod. dec. 610



**PIATTO DESSERT**  
Dessert Plate  
Ø 210 mm - 8 1/4"  
CT12 - Q.P. 1.260  
Cod. 4.50050  
Cod. dec. 395



**PIATTO DESSERT**  
Dessert Plate  
Ø 210 mm - 8 1/4"  
CT12 - Q.P. 1.260  
Cod. 4.50050  
Cod. dec. 630



**PIATTO DESSERT**  
Dessert Plate  
Ø 210 mm - 8 1/4"  
CT12 - Q.P. 1.260  
Cod. 4.50050  
Cod. dec. 600



**PIATTO DESSERT**  
Dessert Plate  
Ø 210 mm - 8 1/4"  
CT12 - Q.P. 1.260  
Cod. 4.50050  
Cod. dec. 610

